

LPRHD2M-622M

Quick Start Guide



Mount Camera

Adjust position and set Zoom.

Use Joystick to adjust Zoom and Focus

Press Joystick down centered to enter setup menu



Set Exposure options: "Dim" or "Bright".



It is important to set this for the working environment such as daytime or night. Also angle or direction of the sun. If there will be a lot of sunlight it can wash out the image in the daytime. This unit does not have separate settings for daytime and night periods.

Depending on the orientation of the mounting you can set the "Image Flip" to match correct orientation.

